



Quality aircraft since 1974

SERVICE LETTER September 20-02

Issue Date

Thursday, September 19, 2002

Subject/Purpose

This Service Letter is for adding OPTIONAL fuel primers to the engine cylinders.

Affected Models

The affected models are aircraft CH 2000 serial numbers 20-0002 and up.

Compliance Time

Non

Inspection


As required


Required Parts from one cylinder primer to four

Part Number	Description	Qty
20-M-38-3	Fuel primer Atomizer with nut and inside sleeve	4
20-M-38-1	Fuel primer bracket	3
91-546	Fuel primer 3/16 I.D. rubber hose	3
64-2	Tee fitting with nut and inside sleeve	3
1/8CL	1/8 copper line	8 feet

Action

- Install fuel primer Atomizers to cylinders.
- Install the fuel primer 3/16 I.D. rubber hose into the fuel primer brackets
- Install fuel primer brackets 20-M-38-1 to cylinders. Drill holes and trim as required.
- Cut and install 1/8 copper lines to Atomizer and "T" fittings
- Install all above items as per schematics on page two and three.
- Note that the Atomizers and "T" fittings are "brass Compression Fittings" and use standard type 1/8 brass Sleeves (#60-2) for 1/8" copper line.





For additional information contact Zenair Ltd.

ZENAIR LTD, HURONIA AIRPORT, MIDLAND, ONTARIO, CANADA L4R 4K8
TEL:(705) 526-2871 - FAX:(705)526-8022