

REAR HORIZONTAL ATTACHMENT SUB-ASSY

REVISION DATE: 19/02		REVISION: 0		MAN. TO MWO: REAR HORIZONTAL ATTACHMENT SUB-ASSY			
PART NO	REV.	DRAWING	ASSEMBLY	DESCRIPTION	QTY	CODE	BUILDER
20-F-13-2			20-F-13	REAR WING ATTACHMENT BRACKET. DRILL HOLES AS PER DRAWINGS. DRILL THE 1/8"DIA. SPAR ATTACHMENT HOLE. DO NOT DRILL TO 5/16" DIA AT THIS TIME.	2		
20-F-13-1				REAR HORIZONTAL ATTACHMENT CHANNEL.. POSITION THE BRACKETS AS PER DRAWINGS. TOTAL DISTANCE FROM THE SPAR BOLT HOLES IS EXACTLY 1180mm. PARTS CAN BE RIVETED TOGETHER WITH AD-4 OR BOLTED WITH AN3 BOLTS.	1		
20-M-50-1			20-M-50	HT PULLEY SUPPORT ASSEMBLY. INSTALL AS PER DRAWING 640-M-50. THE CENTER PULLY IS LINED UP WITH THE CENTER OF 640-F-13-1	1		
				DATE: SIG:			